TRADEMARK HARDWARE
WORLD OF QUALITY HARDWARE

Installation Guide

Installation Instructions

1. Cut sweep to fit.
2. Close door. Hold sweep at bottom of door. Tap down until contact is made between the sweep and threshold.
3. Mark screw holes.
4. Drill pilot holes for screws using a 7/64" drill bit.
5. Install with screws provided.
6. Adjust position so sweep does not impede proper closing and latching of door.

SKU: N200S

www.tmhardware.com 845-388-1300 845-388-1388 sales@tmhardware.com