



**TRADEMARK
HARDWARE**
WORLD OF QUALITY HARDWARE

Installation Guide

Installation Instructions

1. Cut threshold to the required size.
2. Notch around door frame, if desired.
3. Attach threshold with fasteners provided.
4. For moisture control, caulk around base of threshold.

SKU: N430BR



www.tmhardware.com



845-388-1300



845-388-1388



sales@tmhardware.com