



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

Installation Guide

Installation Instructions

1. Assemble ramp by interlocking sections together.
2. Cut ramp to fit.
3. Position return closed end (if ordered) on each side of ramp.
4. Drill and counter sink screw holes in ramp aligned with holes in RCE.
5. Install ramp with screws provided.
6. Caulk around base of ramp and RCE for moisture control.

SKU: NR200



www.tmhardware.com



845-388-1300



845-388-1388



sales@tmhardware.com