TRADEMARK HARDWARE
WORLD OF QUALITY HARDWARE

Installation Guide

Installation Instructions

Follow directions for interlocking ramp assembly.

FOR TWO PIECE RCE-30

1. Install 21" RCE first.
2. Butt 12" RCE section against the 21" RCE.
3. Drill and countersink screw holes in ramp aligned with holes in RCE.
4. Install with screws provided.

SKU: NRCE-30

www.tmhardware.com 845-388-1300 845-388-1388 sales@tmhardware.com