



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

Installation Guide



Installation Instructions

1. Ramp may be cut in field to fit floor conditions.
2. Apply a solid bead of adhesive to underside of ramp at perimeter edges. Then apply several beads of adhesive in a criss-cross pattern to underside of ramp, so when set in place the adhesive spreads to thinly cover entire underside of ramp.

NOTE: Adhesive must be a type designed to bond rubber, concrete, wood, metal or other material to which ramp is being applied. (NGP black silicone adhesive #RR-5007BL is specifically designed for use to install this rubber ramp.)

3. Affix Rubber Ramp to desired location.

IMPORTANT NOTICE: DO NOT WALK ON OR APPLY WEIGHT TO RUBBER RAMP FOR 24 HOURS ALLOWING ADHESIVE TO FULLY CURE.

SKU: NRR952



www.tmhardware.com



845-388-1300



845-388-1388



sales@tmhardware.com